



<p>①</p> <p>897</p> <p>(I) : × 7 (II) : × 7 K1-39485</p>	<p>②</p> <p>980</p> <p>(I) : × 1 (II) : × 1 K1-39470</p>		<p>③</p> <p>(I) : × 2 (II) : × 2 K2-39430</p>	<p>④</p> <p>(I) : × 2 (II) : × 0 K1-30020</p>		
<p>⑦</p> <p>Ø 42</p> <p>1000</p> <p>(I) : × 1 (II) : × 1 K1-39110</p>		<p>⑤</p> <p>(I) : × 7 (II) : × 7 K1-39050</p>	<p>⑥</p> <p>(I) : × 1 (II) : × 0 K1-19340</p>			
<p>⑧</p> <p>(I) : × 2 (II) : × 0 K1-39010</p>	<p>⑨</p> <p>150</p> <p>(I) : × 0 (II) : × 1 K1-39011</p>	<p>⑩</p> <p>(I) : × 0 (II) : × 1 K1-39012</p>	<p>⑪</p> <p>(I) : × 2 (II) : × 0 K2-39190</p>	<p>⑫</p> <p>68</p> <p>(I) : × 1 (II) : × 0 K1-39472</p>		
<p>⑭</p> <p>(I) : × 1 (II) : × 0 K2-39465</p>						
<p>⑳</p> <p>(I) : × 6 (II) : × 4 K3-06015 Ø8×70</p>	<p>㉑</p> <p>(I) : × 6 (II) : × 4 K3-04028 Ø8</p>	<p>㉒</p> <p>(I) : × 6 (II) : × 4 K3-08004 Ø10×60</p>	<p>㉓</p> <p>(I) : × 13 (II) : × 11 K3-05020 M8×8</p>	<p>㉔</p> <p>(I) : × 7 (II) : × 7 K3-01001 M5×14</p>	<p>㉕</p> <p>(I) : × 7 (II) : × 7 K3-03020 M5</p>	<p>㉖</p> <p>(I) : × 1 (II) : × 1 K3-90001</p>

I	II
Start kit	Extension kit
Kit de départ	Kit de suite
Startpaket	Extrapaket
Startpakke	Ekstrapakke









